
yourbabiie

BELGRAVIA

Travel System

Instruction Manual



Please always read all the instructions provided carefully before use,and keep the care and maintenance instruction for further reference.

IMPORTANT! KEEP FOR FUTURE REFERENCE

COMPONENTS




1. Seat
2. Canopy
3. Frame
4. Bumper Bar
5. 2 Front Wheels & 2 Rear Wheels
6. Carry Cot
7. Carry Cot Handle
8. Car Seat Adaptors
9. Car Seat

Open the Stroller


1a. (1) Unlock the stroller as the arrow indicates.

(2) Pull out and pull up the handle.



2a. Press the button on the handle with your finger at the same time pull up the handle.


2b. When the stroller is opened as pic 2b, you should hear “click” sounds on both sides of the stroller, please examine if the stroller is locked in safety position before you use it.




Assemble / Disassemble Rear Wheels

3a. To assemble the rear wheels: Take one side of rear wheels, insert the rear axle into the plastic hole as shown in picture 3a, until it is locked in position. Install the other side of the rear wheel in the same way.

3b. To disassemble the rear wheels: Pull the rear wheel release knob as shown in Arrow 1, remove the rear wheel in the direction of Arrow 2.




Assemble / Disassemble Front Wheels



4a. To assemble the front wheels: Take one side of front wheels, insert the vertical shaft into the plastic hole on the wheel seat as shown in pic 4a, until it is locked in position, install the other side of the front wheel in the same way.

4b. To disassemble the front wheels: Press the small metal pins as shown in Arrow 1, at the same time use your hand to pull out the front wheel as shown in Arrow 2.

Locking wheels



5a. The front wheels 360 degree rotation

Lift up the plastic button on the front wheels to lock wheel into fixed position. Press down the plastic button to release it, allowing 360 degree rotation (pic 5a).


5b. Applying the brake

Step down on the brake pedal to brake the stroller, lift up the pedal to release the brake (pic 5b).

WARNING: Always lock the brake when putting child in or out of the

6. Assemble the seat

6a. Pull up the lever on the top of the seat back to open the seat and fold the seat.



7a. Assemble the hood

Insert the hood plastic into the seat as shown in pic 7a.

7b. Assemble the bumper

Insert the bumper on both sides of the seat as shown in picture 7a.

Note: Please make sure to lock the bumper in place when you hear a “click” sound.




8. Assemble/detach and reverse the seat

8a. Put down the seat as the arrow indicates. Please make sure to lock the seat in place when you hear a “click” sound.

8b. Press the unlock button on both sides of the seat at the same time pull up the seat to take off the seat.


8c. Pull out the button and lift up the seat as arrow direction in pic 8c, then assemble the seat in opposite direction as picture 8c, insert the seat in the frame, ensuring you hear a “Click” sound to denote it is locked in position.





9a-9b. Adjusting the backrest

Lift up the button as arrow in the pic 9a to adjust the backrest to be in 3 position.




9c.Telescopic handle bar

Press the button as the arrow 1 in pic 9c shows.

9d. Adjusting the footrest


Press the button as arrow in the pic 9d to adjust the footrest in 3 positions.



10. Folding the stroller

10a. Fold the seat

10b. Press the second lock and at the same time press the adjust handle button, then push down the handle with slight force to unlock the stroller.



10c-10d. Lower the handle towards the ground. Once fully lowered and the stroller is fully folded you will hear a “click” sound.




10e. The stroller can stand after folding.



11.Assembling the carrycot

11a-11b. In order to unfold the carrycot remove the bedding and the mattress, and then squeeze the metal tensioners on the bottom plate of the pram body in the direction of the arrows (pic11b), until it locks in special holders. You should hear a “click” sounds locking the tensioner in the holder.



NOTE! The carrycot body is designed for children up to 6 months old weighing up to 9 kg, which cannot sit, kneel or crawl by themselves. Stop using the carrycot if your child starts sitting, kneeling or crawling by itself.
WARNING: Do not use an additional mattress.
The carrycot canopy has 4-step adjustment. In order to adjust it, press simultaneously the buttons located at the base of the carrying handle and adjust the desired position.
NOTE! The external canopy cannot be used as a carrying handle.
NOTE! Make sure that the carrying handle is locked in the correct position before you move the carrycot.
WARNING: Do not carry or the lift carry cot by the handle. Always use 2 hands to lift and carry the carrycot by the body of the carrycot.

11c. Insert the carrycot handle in the carrycot housing, adjust the canopy of the carrycot to the top position, insert the bedding and the mattress and pull the zipper of the footcover.




NOTE! The carrycot can be assembled only back to the direction of travel (in this setting, the person pushing the pram is face to face with a child)

NOTE! Lock the safety brake before you assembly the carrycot on the stroller frame.

12a. Put the carrycot onto the stroller in a parent-facing position until you hear a “click” sound.

12b. Press the buttons on the both sides of the carrycot upwards to take off the carrycot from the stroller frame.

WARNING: Always check the carrycot is secure once locked in place by gently pulling up on either side.




13. Using the safety belt


Pic 13a-13b: There are 2 position for safety belt, the top position is suitable for one baby more than 6 months, the bottom position is suitable for one baby under than 6 months. Click together the buckle to lock the safety belt on both sides as 13b.

Press the middle button to release the safety button as 13b.

You can adjust the length of the seat belt by pulling the safety buckle on both sides as needed.




14. Foot rest length adjustment



Pic 14: The length of the foot rest is adjustable, you can adjust the foot rest by pushing the button under the foot rest as pic 14. Press the button down at the same time pull the foot rest to make the foot rest become longer. Press the button down at the same time and push the foot rest inwards to make the foot rest become shorter.

15. Install and take off the adaptor for car seat:



1. Insert the adaptors into the car seat in the right direction as pic 15 indicated, untill you hear a “click” sound.

2. Press the button at the side of the car seat and at the same time pull out the car seat adaptor with slight strenth as Pic 15, you can take off the car seat adaptor.

16. Install and take off the car seat from the stroller:



16a. Put the car seat with the adaptor right above the stroller frame letting the adaptor alignment with the lock metal on the stroller, then push the car seat down with slight strength until you hear a “click” sound, meaning the car seat is properly installed in the stroller frame.


NOTE: Only use the Car Seat on the stroller frame in a parent-facing positon.

WARNING: Always check the car seat is secure once locked in place by gently pulling up on either side.


16b. Press the buttons at the middle of the adaptor at the same time pull up the car seat adaptor,you can take off the car seat from the stroller .

Do not use rearward-facing in seating positions where an active frontal airbag is installed.






















Installing position of the child seat in vehicle




- When used as an infant carrier with ISOFIX base, this type of child safety seat is suitable for fixing into the seat positions of the cars equipped with ISOFIX system that is fitted in accordance with ECE R14.
- When used as an infant carrier module without ISOFIX base, this type of child safety seat is suitable for the car equipped with the 3-point belts and approved by ECE R16.

[redacted]

1 Not to use rearward-facing in seating positions where an active frontal airbag is installed.

2 Only install in this position if three-point safety belt are fitted.

Usage of buckle



Step 1: Insert the left and the right pieces of buckle together.
Step 2: Insert the two pieces into the slot of the buckle at the same time. Hearing "click" means the buckle is connected. Pull the pieces of the buckle and check whether the buckle is locked correctly.
Step 3: If you want to release the safety belts, you need to press the red button, then the pieces pop up.


Check the height of the harness


- Always check whether the Y-shaped belts are at the correct height for your child. If not, repeat adjusting the height of headrest.





If the height of Y-shaped belt is not in accordance with requirement, please adjust according to the following steps:


Step 1: Press the red button of buckle, the two buckle pieces will eject automatically.
Step 2: Press the seat belt adjustment button to change the position of shoulder Y-shaped belts .









A
B
C








Loosen the harness


The Y-shaped belts can be slackened by pressing the adjuster button at th efront of the seat. Press the adjuster as you grip the two Y-shaped belts with your another hand. Pull the Y-shaped belt towards you to loosen the Y-shaped belts.













Tightening the harness

Pull the front upwards until the Y-shaped belt is fully tightened. The Y-shaped belt should be adjusted tightly without causing discomfort to your child. A loose Y-shaped belt can be dangerous.
Check the Y-shaped belt adjuster and tighten it each time when the child is placed in the seat.



Removing the harness



CAR SEAT WARNINGS

- This car seat is suitable for children with a weight from 0 to 13 kg.
- Only suitable for use in vehicles equipped with a three-point safety belt as approved by the ECE regulation No.16 or by other, comparable standards.
- All belts intended for fastening to the restrainer fittings in the vehicle must be tightened. The belts used to hold the child must be fastened tightly. The belts may furthermore not be twisted.
- This child seat must only be installed in a forward facing position in passenger seats. Do not use on side facing or rear facing seats .
- Never use this child seat without fastening the child's harness correctly, and never attempt to use it without fastening it into the car as described in these instructions.
- **DO NOT** modify the seat in any way.
- It is essential to ensure that the crutch belts are fastened as low as possible to ensure that the crutch is retained properly.
- Replace the restrainer fittings if they have been subject to heavy loading due to an accident.
- **WARNING**: It is dangerous to change or supplement the restrainer fittings in any way without approval from the competent authorities and to not precisely observe the assembly instructions for restrainer fittings issued by the manufacturer.
- Do not expose the seat to direct sunlight.
- Car interiors can become very hot when in direct sunlight, it is therefore recommended that the child seat is covered when not in use this prevents components ,particularly those attached to the child seat, becoming hot and burning the child.
- **WARNING**: Do not leave your child unattended in the restrainer fittings.
- Adequately secure items of luggage or other objects which could injure your child in case of a collision.
- **WARNING**: Do not use the child restrainer fittings without seat cover.
- The seat cover is an integral part of the restrainer fittings and may not be exchanged for any other than that stated by the manufacturer.
- Rigid parts and plastic parts must not be jammed during assembly.
- Use the belt guide only as shown in the drawing.
- **WARNING**: This product does not comply to the requirements of EN 12790 for reclined cradles!
- Never use this product as reclined cradle.

Cleaning

Please be sure to use only original replacement seat covers, as the seat cover is important to the proper functioning of the system. Replacement seat covers are available from your retailer and from main supplier.

The cover can be removed and washed with warm water and a mild detergent. Do not spin, and never tumble dry in an electric clothes dryer (the fabric may separate from the padding).
The plastic parts can be cleaned using soapy water. Do not use harsh cleaning agents (such as solvents). The harness can be removed and washed in lukewarm soapy water.
Caution! Never remove the buckle tongues from the straps.

SAFETY & CARE NOTES

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

Thank you for choosing our product, please always read all the instructions provided carefully before use and remember, your child's safety may be affected if you do not follow these instructions. The stroller is suitable from 0 months to around 5 years of age. The max load of the stroller is 22kg (48 lbs), never overload. This product complies with EN1888-1 & 2:2018

WARNING: NEVER LEAVE YOUR CHILD UNATTENDED.
WARNING: ENSURE that all the locking devices are engaged before use.
WARNING: MAKE SURE the brake system is engaged when putting or taking out the child.
WARNING: To avoid injury ensure that your child is kept away when unfolding and folding this product.
WARNING: DO NOT let your child play with this product.
WARNING: ALWAYS use the restraint system seat belt to avoid serious injury from falling or sliding out.
It may be dangerous to leave your child unattended.
WARNING: Do not leave the stroller with a baby on a slope, even if the brake is locked.
WARNING: Do not use the stroller if any component is damaged.
WARNING: When making any adjustments make sure that the movable parts are not close to the baby's body.
WARNING: Accessories which are not approved by the manufacturer shall not be used.
WARNING: Avoid placing the stroller near naked heat sources such as electric bar fires, gas fires, etc. or where a child could gain access to any other kinds of hazards.
WARNING: ALWAYS use the crotch strap in combination with the waist belt.
WARNING: ALWAYS use the harness provided and make sure the harness is correctly fitted.
WARNING: Any load attached to the handle affects the stability of the stroller.
WARNING: Use the stroller for only one child at a time.
WARNING: The maximum permissible loading for shopping basket is 3kg (6.6 lbs).
WARNING: Excessive weight may cause a hazardous unstable condition to exist.
WARNING: DO NOT use if any parts is broken, torn or missing.
WARNING: This stroller is not suitable for children over 22kg (48lbs)
WARNING: Only replacement parts supplied or recommended by the manufacture/distributor shall be used.
WARNING: This product is not suitable for running or skating.
WARNING: DO NOT place the parcels or accessory items or both on the stroller may cause the unit to become unstable.
WARNING: The bassinet is suitable for child under 6 months and the max weight is 9 kg (19.5 lbs).
WARNING: Do not use an additional mattress in the product.

Your child's safety is your responsibility
If you have a problem with this product or require replacement parts, please visit www.mybabiie.com/support
Register your product at: www.mybabiie.com/warranties

CLEANING & WASHING

Please note the textile designation. Metal and plastic parts should be cleaned with a damp cloth and mild detergent. Do not use abbrasive agents. Please check on a regular basis that the brakes, wheels, latches, connecting elements, belt systems and seams are properly functional.


In case of any damage or irregularities, the product no longer use. Don't expose the product to strong sunshine After use in rain or snow, the wheels should be lubricated and the vehicle dried to prevent rust. Care for, clean and check this product regularly. Don't use accessories that have not been approved by the manufacturer.

For the proper functioning of the wheelchair, we recommend regular cleaning and lubrication of all moving parts, mechanisms and wheel axles with the appropriate cleaning agents and lubricants.

STROLLER DO'S & DON'TS




Do use your brakes!
Ensure the parking brake is engaged during the loading and unloading of children & when the stroller is stationery.



Do always use the restraint system!
Ensure that the child restraint system is correctly fitted at all times.



Do keep your stroller clean and dirt free.
Use a clean white cloth, warm water and a mild detergent to keep your stroller clean.



Do always keep two hands on the handles when pushing.
You could lose control of your stroller if not steering with both hands.



Do follow manufacturers instructions when assembling and using your stroller.
For safety, please refer to our instruction manuals or contact customer support if you're unsure.



Don't use your stroller up and down stairs!
Don't use your stroller up or down stairs or to bump kerbs.



Don't hang bags off the handles!
Bags and other items should not be hung from the handles as this can affect the stability of the stroller.



Don't run or skate with your stroller !
Our products are not suitable for running or skating.



Don't carry the stroller with baby inside!
Our strollers are not designed to be carried with your baby inside them.



Don't put hot drinks in the cup holder.
Hot drinks burn and can easily spill from the bottle holder.



Don't jetwash your stroller.
Some jet washers are very powerful and could damage parts of your stroller !



Don't leave your child un-attended in their stroller.
Always keep your child and stroller in view to avoid accidents.



Don't treat your stroller like a trolley.
Don't load your stroller up with all your shopping as they are not built for this purpose and could cause damage.



Don't use your stroller as a bumper cart!
Damage can easily occur if your stroller is knocked into other things.



Don't smoke around your stroller
We wouldn't want your stroller or little one getting hurt or damaged!



Don't leave your stroller unattended on extreme gradients.
Even with your brakes on your stroller is at risk from tipping or sliding on extreme gradients!



Don't sit in the strollers unless the user is under the guideline weight.
Our strollers are designed to hold a maximum weight. If exceeded this will cause damage!



Do enjoy your product!
Go out and have fun adventures with your little one!

yourbabiie

tell your story

Register your product at:

www.mybabiie.com/warranties

In the first instance of needing assistance please contact your original place of purchase.

This product qualifies for 12 month warranty when registered through our site

@YourBabiieOfficial

Your Babiie. Part of My Companiie Ltd
Ashford, Kent, TN23 3GP